

LED SPIDER MOVING HEAD LIGHT

MJ-1031C(4IN1)



INSTRUCTION MANUAL

=====PROFESSIONAL LED LIGHTING =====

Thank you for choosing our LED spider moving head light. For the sake of your safety, Please read and follow these instructions carefully and keep this manual in a safe place for future reference.

Catalogue

Chapter	Page
Safe Usage Of The Product -----	3
Install The Equipment -----	4
Power Code Connection -----	4
DMX Connection -----	4
DMX Terminator -----	5
Function Set -----	5
Menu Function Description -----	6
Maintenance -----	6
Keeping The Product Clean -----	6
Trouble Shooting-----	7
Equipment and Appendix-----	7
Channel List-----	7
Technical Parameters-----	9

☆Important notice:

- In this instruction for use contains about the installment and the use aspect important information of the LED moving head. When installing and using, you need to look this usage instruction strictly.
- Before open the LED moving head and if you want to do the repair work, please make sure the power source is at the separation condition.
- Every unit is tested completely and packed properly by the manufacturer. Please make sure the packing and the unit are in good condition before installation and use. Should there be any damage caused by transportation, consult your dealer and do not use the unit. Any damage caused by improper use will not be assumed by the manufacturer or dealer.

Attention: Unceasingly carries on the product improvement about our company the policy, in this instruction booklet carries the data will have the possibility to be able to change in the future, when no longer separate notice change matters concerned. Our company retains when the product improvement changes the related specification the authority. This instruction booklet publisher cannot be responsible regarding this instruction booklet in information accuracy, also cannot the related consequence which causes regarding these information be responsible.

SAFE USAGE OF THE PRODUCT



When unpacking and before disposing of the carton, check there is no transportation damage before using the product. Should there be any damage caused by transportation, consult your dealer and do not use the apparatus.

The product is for indoor use only, IP20. Use only in dry locations. Keep this device away from rain and moisture, excessive heat, humidity and dust. Do not allow contact with water or any other liquids.

The product is not designed or intended to be mounted directly on to inflammable surfaces

The product is only intended for installation, operation and maintenance by professional person.

The product must be installed in a location with adequate ventilation, at least 50cm from adjacent wall surfaces. Be sure that no ventilation slots are blocked.

Do not project the beam onto inflammable surfaces, minimum distance is 5m.  5m 

Avoid direct exposure to the light from the lamp. The light is harmful to the eye.

Do not attempt to dismantle or modify the projector in any way.

Electrical connection must only be carried out by qualified personnel.

Before installation, ensure that the voltage and frequency of power supply match the power requirements of the projector.



It is essential that each projector is correctly earthed and that electrical installation conforms to all relevant standards.

Do not connect this device to any other types of dimmer apparatus.

Make sure that the power-cord is never crimped or damaged by sharp edges. Never let the power-cord come into contact with other cables. Only handle the power-cord by the plug. Never pull out the plug by tugging the power-cord.

Keep the optical system clean. Do not touch the LED lens with bare hands.

The product should always be installed with a secondary safety fixing. On the projector base brack, there is a hole for the safety cord provided. It should be attached as shown in “installing the projector” section.

LED lens shall be changed if they have become visibly damaged to such an extent that their effectiveness is impaired, for example by cracks or deep scratches.  

Exterior surface temperatures of the luminaire after 5 minutes operation is 40 °C, when steady state is achieved 50 °C.

There is no user serviceable parts inside the projector, do not open the housing and never operate the product with the covers removed.

If you have any questions, don't hesitate to consult your dealer or manufacturer.

★Always disconnect from the mains, when the device is not in use or before cleaning it or before attempting any maintenance work !

Install The Equipment:

Use 1pcs clamp (need to purchase). Use clamp fix with light hook which in the packing box with light, then use screw install to the bottom of lamp. Hang the fixture on the structure and fasten the screws attached to each clamp. Make sure the light is installed reliable, and confirm the light which you fixed is strong enough for hanging the light. Base on safety reason, please according to the above picture using safety wire cross the light to make it strong enough again.

Warning!

1. Hook and clamp only use for hanging the light. Do not use clamp as a tool to move fixtures.
2. Don't use the handle of the moving head light to fixed or lift!

Power Code Connection:

Connect the power cord as follows:

L (live) =brown


E (earth) =yellow/green

N (neutral) =blue

Use the plug provided to connect the mains power to the projector paying attention to the voltage and frequency marked on the panel of the projector. It is recommended that each projector be supplied separately so that they may be individually switched on and off.

★It is essential that each projector is correctly earthed and the electrical installation conforms to all relevant standards.

DMX Connection:



Connection between the controller and a projector and between one projector and another must be made with a 2 core-screened cable, with each core having at least a 0.5mm diameter. Connection to and from the projector is via cannon 3 pin (which are included with the projector) XLR plugs and sockets. The XLR's are connected as shown in the figure above.


Note: Care should be taken to ensure that none of the pins touch the metallic body of the plug or each other. The body of the plug is not connected in any way. The XLED 590 accepts digital control signals in protocol DMX512 (1990).

Connect the controller's output to the first fixture's input, and connect the first fixture's output to the second fixture's input and connect the rest fixtures in the same way. Eventually connect the last fixture's output to a DMX terminator as shown in the figure below.


DMX Terminator:

In the Controller mode, at the last fixture in the chain, the DMX output has to be connected with a DMX terminator. This prevents electrical noise from disturbing and corrupting the DMX control signals.

The DMX terminator is simply an XLR connector with a 120Ω (ohm) resistor connected across pins 2 and 3, which is then plugged into the output socket on the last projector in the chain. The connections are illustrated below.



Function Set:



Use button switch and LED display, can set the address code and function code easily.

Check or modify lighting function settings, Press the **MENU** button. LED display panel will display function menu of lighting. Function operation menu all have corresponding submenu. Each menu all represent the specific functions of lamps, specific see below "operation menu" section.

Set or browse function setting of lamp, Press **UP** or **DOWN** button.

Press **ENTER** button to save your changes or to **ENTER** submenu, Press **UP** or **DOWN** can change value(Plus or reduce number).

According to the **ENTER** key to return to the last menu.

Menu Function Description:

DMX Address	A001---A512
Channel Mode	11CH,37CH, 39CH
Show Mode	SH 0---SH24,
Slave Mode	MAST, SL 1, SL 2,
Black Out	YES, NO
Sound State	State
Sound Sense	(0 closed, 100 is the most sensitive)
Pan Inverse	YES, NO
Tilt Inverse	YES, NO
Back Light	ON, OFF
Auto Test	Test
Fixture Time	0---9999
Firmware Version	V104
Defaults	YES, NO
System Reset	YES, NO

Maintenance:

To prolong the life of the projector, some maintenance work has to be done to ensure the LED optical system in good condition. If the projector does not function, check the fuses on the power socket of the projector, they should only be replaced by fuses of the same specification. Should these be damaged, call a qualified technician before replacement. The projector has thermal protection device that will switch off the projector in case of overheating. Should either of these operate, check that the fans are not blocked, and if they are dirty, clean them before switching on the projector again. Check that the fans are operational, if not, call a qualified technician.

☆Any maintenance work should only be carried out by qualified technicians.

Keeping The Product Clean:

To ensure the reliability of the projector, it should be kept clean. It is recommended that the fans should be cleaned every 15 days. LED lens should also be regularly cleaned to maintain an optimum light output.

Cleaning frequency depends on the environment in which the fixture operates: damp, smoke or particularly dirty surroundings can cause greater accumulation of dirt on the unit's optics. A soft cloth and typical glass cleaning products should be used for cleaning. It is recommended to clean the external optics at least once every 15 days.

☆Do not use any organic solvent, e.g. alcohol, to clean housing of the apparatus.

Trouble Shooting:

Problem	Answer
The LED moving head light doesn't switch on.	Check the fuse the power socket
Although shines, but the LED moving head lamp doesn't accept the instruction of the controller.	Check the digital start address and also check the connection situation of the communication control line
LED moving head lamp only can work intermittently.	Inspect the power supply and voltage is whether normal.
Do not receive the DMX512 signal.	Whether the signal lines do contact well or broken.
The light beam appears gloomily.	Check that the heat dissipation system is running normally or Inspect the optics part is whether clean.

☆Other maintain work should by the specialist which has the experience to carry on.

Equipment and Appendix:

The packing list of this light as follows:

- ☆ Led moving head light 1pcs
- ☆ Power Cable 1pcs
- ☆ XLR connector 1unit
- ☆ Light Hook 1pcs
- ☆ Screw 2pcs
- ☆ The Product of Instruction 1pcs

Channel List:

11Channel model

Channel	Function	Value
CH1	Pan	0-255
CH2	Tilt 1	0-255
CH3	Tilt 2	0-255
CH4	Main dimming	0-255
CH5	Strobe	0-255 stroboscopic from slow to fast
CH6	R dimming	0-255 (linear dimming from dark to bright)
CH7	G dimming	0-255 (linear dimming from dark to bright)
CH8	B dimming	0-255 (linear dimming from dark to bright)
CH9	W dimming	0-255 (linear dimming from dark to bright)

CH10	The effect	0, 7 no effect,8-17 effect 1,18-27 effect 2,28-37 effect. 3,38-47 effect 4, 48-57 effect 5, 58-67 effect of 6, 68-77 results 7, 78-87 effect 8 88-97 effect 9, 98-107 effect 10, 108-117 results 11, 118-127 effect 12, 128-136 results 13,137-146 results 14, 147-156 results 15, 157-166 results 16,167-176 effect of 17, 177-186 results 18 , 187-196 effect of 19, 197-206 effects of 20, 207-216 effect 21, 217-226 results 21, 227-236 results 23,The 237-246 effect 24, 247-255 results 25
CH11	speed	0-255 from fast to slow

37Channel model

Channel	Function	Value
CH1	Pan	0-255
CH2	Tilt 1	0-255
CH3	Tilt 2	0-255
CH4	Main dimming	0-255
CH5	Strobe	0-255
CH6	R1 dimming	0-255 (linear dimming, from dark to bright)
CH7	G1 dimming	0-255 (linear dimming, from dark to bright)
CH8	B1 dimming	0-255 (linear dimming, from dark to bright)
CH9	W1 dimming	0-255 (linear dimming, from dark to bright)
CH10	R2 dimming	0-255 (linear dimming, from dark to bright)
CH11	G2 dimming	0-255 (linear dimming, from dark to bright)
CH12	B2 dimming	0-255 (linear dimming, from dark to bright)
CH13	W2 dimming	0-255 (linear dimming, from dark to bright)
CH14	R3 dimming	0-255 (linear dimming, from dark to bright)
CH15	G3 dimming	0-255 (linear dimming, from dark to bright)
CH16	B3 dimming	0-255 (linear dimming, from dark to bright)
CH17	W3 dimming	0-255 (linear dimming, from dark to bright)
CH18	R4 dimming	0-255 (linear dimming, from dark to bright)
CH19	G4 dimming	0-255 (linear dimming, from dark to bright)
CH20	B4 dimming	0-255 (linear dimming, from dark to bright)
CH21	W4 dimming	0-255 (linear dimming, from dark to bright)
CH22	R5 dimming	0-255 (linear dimming, from dark to bright)
CH23	G5 dimming	0-255 (linear dimming, from dark to bright)
CH24	B5 dimming	0-255 (linear dimming, from dark to bright)
CH25	W5 dimming	0-255 (linear dimming, from dark to bright)
CH26	R6 dimming	0-255 (linear dimming, from dark to bright)
CH27	G6 dimming	0-255 (linear dimming, from dark to bright)
CH28	B6 dimming	0-255 (linear dimming, from dark to bright)
CH29	W6 dimming	0-255 (linear dimming, from dark to bright)
CH30	R7 dimming	0-255 (linear dimming, from dark to bright)
CH31	G7 dimming	0-255 (linear dimming, from dark to bright)
CH32	B7 dimming	0-255 (linear dimming, from dark to bright)
CH33	W7 dimming	0-255 (linear dimming, from dark to bright)
CH34	R8 dimming	0-255 (linear dimming, from dark to bright)
CH35	G8 dimming	0-255 (linear dimming, from dark to bright)
CH36	B8 dimming	0-255 (linear dimming, from dark to bright)
CH37	W8 dimming	0-255 (linear dimming, from dark to bright)

39Channel model

Channel	Function	Value
CH1	Pan	0-255
CH2	Tilt 1	0-255
CH3	Tilt 2	0-255
CH4	Main dimming	0-255
CH5	Strobe	0-255
CH6	R1dimming	0-255 (linear dimming, from dark to bright)
CH7	G1dimming	0-255 (linear dimming, from dark to bright)
CH8	B1 dimming	0-255 (linear dimming, from dark to bright)
CH9	W1 dimming	0-255 (linear dimming, from dark to bright)
CH10	R2dimming	0-255 (linear dimming, from dark to bright)
CH11	G2dimming	0-255 (linear dimming, from dark to bright)
CH12	B2 dimming	0-255 (linear dimming, from dark to bright)
CH13	W2 dimming	0-255 (linear dimming, from dark to bright)
CH14	R3dimming	0-255 (linear dimming, from dark to bright)
CH15	G3dimming	0-255 (linear dimming, from dark to bright)
CH16	B3 dimming	0-255 (linear dimming, from dark to bright)
CH17	W3 dimming	0-255 (linear dimming, from dark to bright)
CH18	R4dimming	0-255 (linear dimming, from dark to bright)
CH19	G4dimming	0-255 (linear dimming, from dark to bright)
CH20	B4 dimming	0-255 (linear dimming, from dark to bright)
CH21	W4 dimming	0-255 (linear dimming, from dark to bright)
CH22	R5 dimming	0-255 (linear dimming, from dark to bright)
CH23	G5dimming	0-255 (linear dimming, from dark to bright)
CH24	B5 dimming	0-255 (linear dimming, from dark to bright)
CH25	W5 dimming	0-255 (linear dimming, from dark to bright)
CH26	R6dimming	0-255 (linear dimming, from dark to bright)
CH27	G6dimming	0-255 (linear dimming, from dark to bright)
CH28	B6 dimming	0-255 (linear dimming, from dark to bright)
CH29	W6 dimming	0-255 (linear dimming, from dark to bright)
CH30	R7dimming	0-255 (linear dimming, from dark to bright)
CH31	G7dimming	0-255 (linear dimming, from dark to bright)
CH32	B7 dimming	0-255 (linear dimming, from dark to bright)
CH33	W7 dimming	0-255 (linear dimming, from dark to bright)
CH34	R8dimming	0-255 (linear dimming, from dark to bright)
CH35	G8dimming	0-255 (linear dimming, from dark to bright)
CH36	B8 dimming	0-255 (linear dimming, from dark to bright)
CH37	W8 dimming	0-255 (linear dimming, from dark to bright)
CH38	The macro	0-7 no effect,8-17 effect 1,18-27 effect 2,28-37 effect. 3,38-47 effect 4, 48-57 effect 5, 58-67 effect of 6, 68-77 results 7, 78-87 effect 8 88-97 effect 9, 98-107 effect 10, 108-117 results 11, 118-127 effect 12, 128-136 results 13,137-146 results 14, 147-156 results 15, 157-166 results 16,167-176 effect of 17, 177-186 results 18 , 187-196 effect of 19, 197-206 effects of 20, 207-216 effect 21, 217-226 results 21, 227-236 results 23,The 237-246 effect 24, 247-255 results 25
CH39	speed	0-255 from fast to slow

Technical Parameters:

Voltage: AC100V-240V; 50/60Hz

Power Consumption: 120W (220V)

LED Bulbs: 10W*8LEDs 4IN1 LED

LED Current: 700mA

LED Lifetime: 50000Hours

Adjusts the light: 0-100 electron adjusts the light

Strobe: 1-25/second high speed strobe

Pan Movement: 540 °

Tilt Movement: 180 °

Beam Angle: 2 °

Control mode: DMX 512, Stand –alone mode, Self-test mode, Sound, Master/slave

DMX Channel: 11/37/39CH

Control Panel: LCD display panel

IP Grade: IP33

Work Environment Temperature: -20 °C~40 °C

Net weight:7.2KG

Gross Weight: 8.5 kg

Package Size:46 x 32x 29cm